



ENPAC
CORPORATION

EXTRA LARGE TOTE BIN WITH WHEELS P/N 1530 & 1531 Assembly Instructions

NOTE: The wheel kit is located inside of the tote. If the wheels are to be installed onto a loaded unit, make sure that the lid is secure to ensure that the contents do not spill during installation.

STEP 1: The wheel kit includes (16) 5/16" – 18 x 1" long bolts, (16) 5/16" lockwashes, 2 fixed casters, and 2 swivel casters. Use (1) bolt and (1) lockwasher per hole to attach the caster to the threaded inserts in the bottom of the tote.



STEP 2: Assemble similar casters (swivel or fixed) onto the same side that the unit will be pushed from. Typically these will be located on either side of the forklift channels as shown (swivel casters shown).